


1. XM Sports

XM Sports is a service included with an XM Satellite Radio subscription. This service is also available with an XM TravelLink subscription. With this service, you can receive updates via the navigation system on your personally selected sports teams.

- 1 Press the “MENU” button on the Remote Touch.



- 2 Select “Info/Apps”.



- 3 Select “XM Sports”.



- The “XM Sports” screen is displayed.
- The following operations can be performed:
 - Sports information can be received. (See page 165.)
 - XM Sports settings can be set. (See page 165.)

RECEIVE SPORTS INFORMATION

The desired teams must be added in order to receive information. (See page 165.)

- 1 Press the **"MENU"** button on the Remote Touch. (See "Remote Touch" on page 10.)
- 2 Select **"Info/Apps"** on the "Menu" screen.
- 3 Select **"XM Sports"** on the "Information" screen.
- 4 Select the desired team to receive information.



- Teams for which there is no current data available will be dimmed and you will not be able to select them.

- 5 Select the individual information item to hear it, or select **"Read All"** to hear all available information for that team.



- The selected information will be read out in its entirety.


XM Sports SETTINGS – ADD OR DELETE TEAMS

To input your personalized XM Sports team.

- 1 Press the **"MENU"** button on the Remote Touch. (See "Remote Touch" on page 10.)
- 2 Select **"Info/Apps"** on the "Menu" screen.
- 3 Select **"XM Sports"** on the "Information" screen.
- 4 Select **"Options"**.



- 5 Perform each setting according to the procedures outlined on the following pages.



- Personalized XM Sports teams can also be input from the "Setup" screen. (See "XM SETTINGS" on page 181.)

ADD SPORTS TEAM

- 1 Select “Add Sports Team”.



- Up to 5 teams can be added and saved in the system for which information will be received. The desired teams can be changed at any time. Teams must be added one at a time.

- 2 Select the desired sporting league of the team.



- 3 Select the name of the desired team to be added from the list that appears.



- 4 Select “Yes” to confirm or “No” to cancel.

DELETE SPORTS TEAMS

- 1 Select “Delete Sports Teams”.



- 2 Select the individual sports team to be deleted or select “Select All” to delete all the teams, and select “Delete”.




- 3 Select “Yes” to confirm or “No” to cancel.

2. XM Stocks

XM Stocks is a service included with an XM Satellite Radio subscription. This service is also available with an XM TravelLink subscription. With this service, you can receive updates via the navigation system on your personally selected stocks.

- 1 Press the “MENU” button on the Remote Touch.



- 2 Select “Info/Apps”.



- 3 Select “XM Stocks”.




- The “XM Stocks” screen is displayed.
- The following operations can be performed:
 - Stock data can be received. (See page 168.)
 - XM Stocks setting can be set. (See page 168.)

RECEIVE STOCK DATA

You must first add your desired stocks prior to receiving data. (See page 168.)

- 1 Press the **"MENU"** button on the Remote Touch. (See "Remote Touch" on page 10.)
- 2 Select **"Info/Apps"** on the "Menu" screen.
- 3 Select **"XM Stocks"** on the "Information" screen.
- 4 Select an individual stock to hear its related data, or select **"Read All"** to hear the data for all the stocks saved in the system.




- The selected data will be read out in its entirety.
- Stock data may be delayed by approximately 20 minutes.


XM Stocks SETTINGS – ADD OR DELETE STOCKS

To input your personalized XM Stocks settings.

- 1 Press the **"MENU"** button on the Remote Touch. (See "Remote Touch" on page 10.)
- 2 Select **"Info/Apps"** on the "Menu" screen.
- 3 Select **"XM Stocks"** on the "Information" screen.
- 4 Select **"Options"**.




- 5 Perform each setting according to the procedures outlined on the following pages.




- Personalized XM Stocks settings can also be input from the "Setup" screen. (See "XM SETTINGS" on page 181.)

ADD STOCK

- 1 Select "Add Stock".



- 2 Input the desired stock symbol.




- 3 When finished, select "OK".

- Up to 10 individual stock symbols can be added and saved in the system for which information will be received. Stocks must be input one at a time. To enter a stock, the symbol of the desired stock must be known.

DELETE STOCKS

- 1 Select "Delete Stocks".



- 2 Select the individual stock to be deleted or select "Select All" to delete all the stocks, and select "Delete".



- 3 Select "Yes" to confirm or "No" to cancel.


3. XM FUNCTION OPERATION

3. XM Fuel Prices

XM Fuel Prices is a service included with an XM TravelLink subscription. It enables the navigation system to display current fuel prices and gas station locations, which can be set as a destination if desired.

SHOW XM Fuel Prices INFORMATION


- 1 Press the “MENU” button on the Remote Touch.



- 2 Select “Info/Apps”.




- 3 Select “XM Fuel Prices”.



- The “Fuel Price” screen is displayed.

XM Fuel Prices SCREEN



- 1 Gas station name
- 2 Sort


VIEW DETAILED FUEL PRICE INFORMATION

- 1 Press the “MENU” button on the Remote Touch. (See “Remote Touch” on page 10.)
- 2 Select “Info/Apps” on the “Menu” screen.
- 3 Select “XM Fuel Prices” on the “Information” screen.
- 4 Select the desired gas station from the list.




- The location of the selected gas station will be displayed on the map screen.

5 Select "Info".



- When the map scale is at the maximum range of 0.5 miles (800 m), is not shown. When the map scale is at the minimum range of 150 ft. (50 m), is not shown.



"Mark": Select to mark the selected gas station on the map screen.

"Go to": Select to set the selected gas station as a destination with route directions.

"Add to Route": Select to add the selected gas station as a destination.

"Detail": Select to read the selected gas station's information.

- If is selected, the registered phone number can be called.

INFORMATION


- The information displayed is received via satellite radio. Depending on the time the information is received, the displayed information may not be up to date.

XM Fuel Prices SETTINGS

The desired fuel type, preferred brand, and show prices reported can be registered.

REGISTER FUEL TYPE


- Press the **"MENU"** button on the Remote Touch.



- Select **"Setup"**.




- Select **"Other"**.



4 Select "XM Fuel Prices".



5 Select "Fuel Type".



6 Select the desired fuel type.

- "Premium", "Midgrade", "Regular" or "Diesel" can be selected.

7 Select "Save".


REGISTER PREFERRED BRAND

1 Press the "MENU" button on the Remote Touch, then select "Setup".

2 Select "Other" on the "Setup" screen.

3 Select "XM Fuel Prices" on the "Other Settings" screen.

4 Select "Preferred Brand".




5 Select the preferred brand.

6 Select "Save".

REGISTER SHOW PRICES REPORTED

- 1 Press the **"MENU"** button on the Remote Touch, then select **"Setup"**.
- 2 Select **"Other"** on the "Setup" screen.
- 3 Select **"XM Fuel Prices"** on the "Other Settings" screen.
- 4 Select **"Show Prices Reported"**.



- 5 Select the desired period.
 - **"Last 24 Hours"**, **"Last 2 Days"** or **"Show All"** can be selected.
 - If **"Show All"** is selected, information about gas stations which fuel prices are not provided is also displayed on the list.
- 6 Select **"Save"**.

3. XM FUNCTION OPERATION

4. XM NavWeather™


The subscription-based XM NavWeather™ service allows the navigation system to display weather information on the map screen.

- The following operations can be performed:

- Show XM NavWeather™ information: Weather forecast information is displayed on the map screen. (See page 174.)
- Weather information: Weather information for the selected city is displayed. (See page 176.)
- Weather warnings: Weather warnings issued within a radius of approximately 15 miles (25 km) or 7.8 miles (12.5 km) around the vehicle are displayed on the warning screen. (See page 177.)

SHOW XM NavWeather™ INFORMATION

- 1 Press the **"MENU"** button on the Remote Touch.



- 2 Select **"Info/Apps"**.




- 3 Select **"XM NavWeather"**.



- The XM NavWeather screen is displayed.

XM NavWeather™ SCREEN



- 1 **"Info."**

- When the city icon is selected, **"Info."** is displayed on the map screen. Selecting this screen button displays the **"Forecast"** screen. (See page 176.)

2 City icon

- When this screen button is selected, city names and “Info.” are displayed on the upper part of the screen.

3 “Forecast”

- When this screen button is selected, the city selection screen is displayed.



- Select a city to display weather information. Weather information of the selected city will be displayed. (See page 176.)

4 “Current Location”

- When “Current Location” is selected, the current position is displayed.

5 Zoom in/out screen button


- The scale of the map can be changed. Three zoom levels can be selected; 16 miles (26 km), 30 miles (48 km) and 60 miles (97 km).

6 Weather icons and grids

- Inclement weather information is displayed on the map using weather icons and grids. Selecting an icon shows the related information at the top of the screen.


Icon	Weather
	Tornado
	Hurricane
	Storm
	Flood
	Winter
	Wind
	Extremes
	Other
	Hail storm
	Severe thunderstorm
	Heavy fog
	Heavy freezing rain/ice
	Heavy snow
	Heavy rain

WEATHER INFORMATION



No.	Function
1	Received time
2	City name
3	Today's date
4	Current weather
5	Current temperature
6	Today's weather
7	Tomorrow's weather
8	Day after tomorrow's weather
9	Observed time (Time elapsed since last update)
10	Specified day's weather

- When the specified day's weather screen button is selected, weather information for a specified day is displayed.



No.	Function
1	Daytime weather
2	Nighttime weather
3	Maximum temperature
4	Minimum temperature
5	Precipitation probability

WEATHER WARNINGS

Weather warnings issued within a radius of approximately 15 miles (25 km) or 7.8 miles (12.5 km) around the vehicle are displayed on the warning screen.



“Weather Map”: When this screen button is selected, the “XM NavWeather” screen is displayed.

“OK”: When this screen button is selected, the screen returns to the map of the current position.

XMNavWeather™ INDICATOR



- When an XM NavWeather™ warning is issued within the vicinity, the XM NavWeather™ indicator will appear on the map screen.

5. XM NavTraffic®

The subscription-based XM NavTraffic® service allows the navigation system to display traffic information on the map screen.

The following operations can be performed:


- Show XM NavTraffic® Information: Traffic information is displayed on the map screen. (See page 179.)
- Auto Avoid Traffic: If any heavy congestion or moderate traffic has been detected on the guidance route, it may be possible for you to select another route offered by the system. (See page 129.)
- Traffic Incident Warning: Traffic congestion information is provided using voice guidance. (See page 62.)
- Show Free Flowing Traffic: Freely flowing traffic is shown by the arrow on the map. (See page 129.)

INFORMATION

- When the **"Traffic Information"** indicator is dimmed, "Avoid Traffic", "Traffic Incident Warning" and "Show Free Flowing Traffic" will not operate. (See page 179.)

SHOW TRAFFIC EVENT

- 1 Press the **"MENU"** button on the Remote Touch.



- 2 Select **"Info/Apps"**.




- 3 Select **"Traffic Incidents"**.



- A list of current traffic incidents is displayed along with information on the incident's distance and position relative to the vehicle.

4 Select the desired traffic event.




“On Current Route”: Select to display the traffic congestion information for the selected route, or the road which the current vehicle is on. If a route has not been set, **“On Current Road”** will be displayed.


5 This screen is displayed.



- Guidance route traffic information is displayed on the screen. Select **“Detail”** to display detailed traffic event information.




SHOW XM NavTraffic® INFORMATION

1 Select **“Show on Map”**.2 Select **“Traffic Information”**.

- The **“Traffic Information”** indicator is highlighted.

3 XM NavTraffic® information is displayed on the map screen.

► On the map screen



► On the freeway information screen



1 XM NavTraffic[®] icon

- When any traffic information is received, the XM NavTraffic[®] icon will appear on the map screen. Selecting the XM NavTraffic[®] icon on the screen will start voice guidance for the traffic information. (See page 43.)
- When the XM NavTraffic[®] icon is selected, voice guidance for the traffic information will start even if “Off” for “Traffic Incident Warning” is selected.

2 XM NavTraffic[®] information arrow

- When any XM NavTraffic[®] information is received, the XM NavTraffic[®] information arrow will appear on the map screen. The color of the arrow changes depending on the traffic information received.

Color	Function
Red	Heavy congestion
Yellow	Moderate traffic
Green	Freely flowing traffic

3 XM NavTraffic[®] indicator

- When any XM NavTraffic[®] information is received, the XM NavTraffic[®] indicator will appear on the screen. The color of the indicator changes depending on the traffic information received.

Color	Function
White	Traffic information has been received.
Yellow	Traffic restriction information on the guidance route has been received (screen button*).
Red	Congestion information on the guidance route has been received (screen button*).

*: Selecting the XM NavTraffic[®] indicator will start voice guidance.